


## JIGSAW SAFETY RULES

1. Dress appropriately. Remove all ties, scarves, rings, and watches. Roll up long sleeves and tie back long hair. Loose clothing, hair, and jewelry can easily catch in revolving machine parts.
2. Always wear approved eye protection in the shop.
3. Never use a power tool without your instructor's permission.
4. Never operate a power tool when the instructor is out of the shop.
5. Make sure all safety *guards* are in place.
6. Before you plug in the machine, make sure the switch is in the "off" position.
7. Keep all power cords away from blades and cutters while you work.
8. Make all setups and adjustments with the power off.
9. Clamp the blade securely in both chucks with the teeth pointing down.
10. Adjust the hold down so that it applies light pressure to the stock.
11. Rotate the motor by hand to check that all adjustment have been made properly.
12. Plan cuts to avoid backing out of curves.
13. Do not force the work into the blade. This can cause the blade to bend and break.
14. Keep your finger out of line with the saw. Keep your hands two inches away from the blade.
15. Never leave a machine with the power on. The machine should be completely stopped before you leave it.
16. Keep the work area clean. Remove all debris when you are finish.
17. Never talk to or disturb anyone working with power equipment. If you must talk to an operator, wait until the operator notices you.
18. Relief cuts make it possible to cut sharp outside curves.

# JIG SAW



Use Type 127 or 129 Film

INDUSTRIAL ARTS  
© COPYRIGHT 1964 BY MINNESOTA  
MINING AND MANUFACTURING CO.